

APPLYING SPRAY ON LOGO TIPS

Sometimes the extrusion process for DECKadence Synthetic Boat carpet can leave a film over the PVC threads; therefore for the best vinyl paint/coating cohesion results first clean the general area where you're applying color with a cloth and rubbing alcohol. Apply the rubbing alcohol to a rag and rub the area where you intend to apply the logo, and then let it DRY. You can accelerate the drying process by applying air from your blow dryer to that area.

Do not use a "heat-gun" to dry the area. The vinyl paint dries faster and is more effective from the "airflow process" produced by most standard blow dryers and not necessary the heat.

STEPS:

1. Clean intended area with rubbing alcohol (on a damp Rag) to remove any film then let it DRY.
 2. Apply stencil
 3. Apply Color
 4. Blow Dry
 5. Apply 2nd coat
 6. Remove Stencil
-

Tips: When fading colors always use the darker colors first then transition to lighter, hold the spray can directly ABOVE spraying straight down above the stencil and not at an angle.

