



This is a snapshot of how to plot your templates onto DECKadence for a DECKadence marine fit.

In this scenario there are two sections the runner number **1** and the field number **2** requiring a 6' x 9' section. However if you want one section (no seam) you would need a 6' x 12'.

Simply lay the template over DECKadence pay attention to the **top** and **bottom** so you cut it properly.

Any extra material you do not use, you can place in your deck hatches, and there's several other uses as well.

Note: If you have your **snap in carpet** you can use that for your template go to the ["How to use your existing boat carpet for your DECKadence template"](#) page.